

Norwii Compatibility Guide

Applicable models: N28s, N29s, N95s, N96s, N97s, N10s, N86s

[1] The test results show the compatibility of the default button functions with widely used operating systems and commonly utilized software applications.

[2] If the test results indicate that a certain function is unavailable (x), customers can reprogram the button functions through the Norwii Presenter APP to accommodate their individual preferences.

[3] For Bluetooth Low Energy (BLE) products, connecting to a computer via Bluetooth requires the following:

1) The computer's hardware must support BLE and have a version higher than BLE 4.0; 2) The operating system of the computer must include a compatible BLE driver. It is important to note that many Windows 7 computers are unable to connect via Bluetooth because Microsoft does not officially bring its own BLE driver and the hardware does not support BLE 4.0.

Digital Pointer Series	Operation System→		Windows 7 and above				macOS			Android 4.4 and above		iOS(Test by iPad)			Linux(Ubuntu 18.04)	ChromeOS
	Function of the Presenter	Corresponding keyboard function	MS Office ^[4]	WPS	Open office	Prezi	Keynote	MS Office 365	Prezi	WPS	MS office	Keynote	WPS	MS Office	LibreOffice 6	Google Slides
N28s, N29s, N95s, N96s, N97s, N10s, N86s Test environment: Not start Norwii Presenter App	Page Up	Page Up	√	√	√	√	√	√	√	√	√	X	X	X	√	√
	Page Down	Page Down	√	√	√	√	√	√	√	√	√	X	X	X	√	√
	Arrow Up	Arrow Up	√	√	√	√ ^[2]	√	√	√ ^[2]	√	√	√	√	√	√	√
	Arrow Down	Arrow Down	√	√	√	√ ^[2]	√	√	√ ^[2]	√	√	√	√	√	√	√
	Arrow Left	Arrow Left	√	√	√	√	√	√	√	√	√	√	√	√	√	√
	Arrow Right	Arrow Right	√	√	√	√	√	√	√	√	√	√	√	√	√	√
	Scroll Up	Scroll Up	√	√	√	√ ^[2]	X	√	√ ^[2]	√	X	X	√	X	√	√
	Scroll Down	Scroll Down	√	√	√	√ ^[2]	X	√	√ ^[2]	√	X	X	√	X	√	√
	Full Screen	Shift+F5..... ^[1]	√	√	√	X ^[3]	√	√	X ^[3]	X	X	√	X	X	√	X(Ctrl + Enter)
	Escape Full Screen	ESC	√	√	√	√	√	√	√	√	√	√	√	√	√	√
	Black Screen	b	√	√	√	√	√	√	√	X	√	√	√	√	√	√
	Annotation	Ctrl + P	√	√	X	X	X	X	X	X	√	X	X	X	X	X
	Eraser	a	√	√	X	X	X	NA	X	X	√	X	X	X	X	X
	Mouse Enable	Mouse Move	√	√	√	√	√	√	√	√	√	X	X	X	√	√
	Mouse Left	Mouse LeftClick	√	√	√	√	√	√	√	X	X	X	X	X	√	√
	Mouse Right	Mouse RightClick	√	√	√	√	√	√	√	√	√	X	X	X	√	√
	Volume Control	Vol up/down	√	√	√	√	√	√	√	√	√	√	√	√	√	√
	Virtual Laser ^[5]	Ctrl+L	√	X	X	X	X	X	X	X	X	X	X	X	X	X
	APP-Black Screen ^[6]	/	X	X	X	X	X	X	X							
	APP-Mark ^[6]	/	X	X	X	X	X	X	X							
	APP-Eraser ^[6]	/	X	X	X	X	X	X	X							
	APP-Highlight ^[6]	/	X	X	X	X	X	X	X							
	APP-Magnifier ^[6]	/	X	X	X	X	X	X	X							
	APP-Digital Laser ^[6]	/	X	X	X	X	X	X	X							
N28s, N29s, N95s, N96s, N97s, N10s, N86s Test environment: Started Norwii Presenter App	Operation System→		Windows 7 and later				macOS 10.15 or later			Not Support.						
	Function of the Presenter	Corresponding keyboard function	MS Office ^[4]	WPS	Open office	Prezi	Keynote	MS Office 365	Prezi							
	Page Up	Page Up	√	√	√	√	√	√	√							
	Page Down	Page Down	√	√	√	√	√	√	√							
	Arrow Up	Arrow Up	√	√	√	√ ^[2]	√	√	√ ^[2]							
	Arrow Down	Arrow Down	√	√	√	√ ^[2]	√	√	√ ^[2]							
	Arrow Left	Arrow Left	√	√	√	√	√	√	√							
	Arrow Right	Arrow Right	√	√	√	√	√	√	√							
	Scroll Up	Scroll Up	√	√	√	√ ^[2]	X	√	√ ^[2]							
	Scroll Down	Scroll Down	√	√	√	√ ^[2]	X	√	√ ^[2]							
	Full Screen	Shift+F5..... ^[1]	√	√	√	X ^[3]	√	√	X ^[3]							
	Escape Full Screen	ESC	√	√	√	√	√	√	√							
	Black Screen	b	√	√	√	√	√	√	√							
	Annotation	Ctrl + P	√	√	X	X	X	X	X							
	Eraser	a	√	√	X	X	X	NA	X							
	Mouse Enable	Mouse Move	√	√	√	√	√	√	√							
	Mouse Left	Mouse LeftClick	√	√	√	√	√	√	√							
	Mouse Right	Mouse RightClick	√	√	√	√	√	√	√							
	Volume Control	Vol up/down	√	√	√	√	√	√	√							
	Virtual Laser ^[5]	Ctrl+L	√	X	X	X	X	X	X							
	APP-Black Screen ^[6]	/	√	√	√	√	√	√	√							
	APP-Mark ^[6]	/	√	√	√	√	√	√	√							
	APP-Eraser ^[6]	/	√	√	√	√	√	√	√							
	APP-Highlight ^[6]	/	√	√	√	√	√	√	√							
	APP-Magnifier ^[6]	/	√	√	√	√	√	√	√							
	APP-Digital Laser ^[6]	/	√	√	√	√	√	√	√							

Annotation:

[1] The shortcut keys for the full screen function vary in different operating systems or different presentation software, so we send a series of key combinations to be compatible with various presentation software at the same time. The key combinations include Shift + F5, Command + Return, and so on.

[2] When using Prezi software, please switch the Arrow Up/Arrow Down of the presenter to Page Up/Page Down mode or Arrow Left/Arrow Right mode, because the Arrow Up/Arrow Down mode of the presenter and the scroll wheel mode are smart zoom-in and smart zoom-out functions in Prezi

[3] Prezi software does not have a shortcut key for Full Screen.

[4] The earliest version of Microsoft Office utilized for this test was Microsoft Office 2003.

[5] "Virtual Laser" is to use the "Laser Pointer" function of Microsoft PowerPoint. Only Microsoft Office 2010 or later support the "Laser Pointer" function. The shortcut key is Ctrl + P.

[6] Prefix 'APP' indicates that this function is supported by Norwii Presenter APP.