## Norwii Compatibility Guide

Applicable models: N99, N86

- [1] The test results show the compatibility of the default button functions with widely used operating systems and commonly utilized software applications.
- [2] If the test results indicate that a certain function is unavailable (x), customers can reprograme the button functions through the Norwii Presenter APP to accommodate their individual preferences.
- [3] For Bluetooth Low Energy (BLE) products, connecting to a computer via Bluetooth requires the following:
- 1) The computer's hardware must support BLE and have a version higher than BLE 4.0; 2) The operating system of the computer must include a compatible BLE driver. It is important to note that many Windows 7 computers are unable to connect via Bluetooth because Microsoft does not officially bring its own BLE driver and the hardware does not support BLE 4.0.

Product Series	Operation System→		Windows 7 and above				macOS			Android 4.4 and above		iOS(Test by iPad)			Linux(Ubunt u 18.04)	ChromeOS
	Function of the Presenter	Corresponding keyboard function	MS Office <sup>[4]</sup>	WPS	Open office	Prezi	Keynote	MS Office 365	Prezi	WPS	MS office	Keynote	WPS	MS Office	LibreOffice 6	Google Slides
N99, N86	Page Up	Page Up	√	√	√	√	√	√	√	√	√	X	Х	X	√	√
	Page Down	Page Down	√	√	√	√	√	√	√	√	√	Х	Х	Х	√	√
	Arrow Up	Arrow Up	√	√	√	√ <sup>[2]</sup>	√	√	√ <sup>[2]</sup>	√	√	√	√	√	√	<b>√</b>
	Arrow Down	Arrow Down	√	√	√	√ <sup>[2]</sup>	√	√	√ <sup>[2]</sup>	√	√	√	√	√	√	√
	Arrow Left	Arrow Left	√	√	√	√	√	√	√	√	√	√	√	√	√	√
	Arrow Right	Arrow Right	√	√	√	√	√	√	√	√	√	√	√	√	√	√
	Scroll Up	Scroll Up	√	√	√	√ <sup>[2]</sup>	X	√	√ <sup>[2]</sup>	√	X	X	√	X	√	√
	Scroll Down	Scroll Down	√	√	√	√ <sup>[2]</sup>	X	√	√ <sup>[2]</sup>	√	X	Χ	√	Χ	√	√
	Full Screen	Shift+F5 <sup>[1]</sup>	√	√	√	X <sup>[3]</sup>	√	√	$X_{[3]}$	X	X	√	X	Χ	√	X(Ctrl + Enter)
	Escape Full Screen	ESC	√	√	√	<b>√</b>	√	√	<b>√</b>	√	√	√	√	√	√	√
	Black Screen	b	√	<b>√</b>	√	<b>~</b>	√	√	<b>~</b>	X	√	<b>√</b>	√	√	√	√
	Annotation	Ctrl + P	√	√	X	Χ	X	X	Χ	X	√	X	Χ	Χ	X	X
	Eraser	е	√	√	X	X	Χ	NA	Χ	Χ	√	Χ	Χ	Χ	Χ	X
	Mouse Enable	Mouse Move	√	√	√	√	√	√	√	√	√	X	Χ	Χ	√	√
	Mouse Left	Mouse LeftClick	√	√	√	<b>√</b>	√	√	<b>~</b>	X	X	X	Χ	Χ	√	√
	Mouse Right	Mouse RightClick	√	√	√	√	√	√	√	√	√	X	Х	Х	√	√
	Volume Control	Vol up/down	<b>√</b>	<b>√</b>	V	<b>√</b>	V	V	<b>√</b>	V	√	<b>√</b>	<b>√</b>	V	<b>√</b>	V
	Virtual Laser <sup>[5]</sup>	Ctrl+L	√	X	X	X	X	X	X	X	X	X	Χ	X	X	X

## Annotation

- [1] The shortcut keys for the full screen function vary in different operating systems or different presentation software, so we send a series of key combinations to be compatible with various presentation software at the same time. The key combinations
- [2] When using Prezi software, please switch the Arrow Up/Arrow Down of the presenter to Page Up/Page Down mode or Arrow Left/Arrow Right mode, because the Arrow Up/Arrow Down mode of the presenter and the scroll wheel mode are smart
- [3] Prezi software does not have a shortcut key for Full Screen.
- [4] The earliest version of Microsoft Office utilized for this test was Microsoft Office 2003.
- [5] "Virtual Laser" is to use the "Laser Pointer" function of Microsoft PowerPoint. Only Microsoft Office 2010 or later support the "Laser Pointer" function. The shortcut key is Ctrl + P.
- [6] Prefix 'APP' indicates that this function is supported by Norwii Presenter APP.