

NORWii

Product User Manual

N10s Pro



Be sure to read this user manual carefully before using the wireless presenter and keep it for future reference.

This product can generate laser beam.
DO NOT STARE INTO BEAM OR
EXPOSE USERS OF TELESCOPIC
OPTICS. AVOID DIRECT EYE
EXPOSURE. Do not shine the laser
beam on people's or animal's eyes to
avoid eye damage! Do not give this
product to children as a toy!

Warning label for red laser product:



Warning label for green laser product:



Safety warning

1. This product is equipped with a built-in lithium battery, and it is prohibited to disassemble, collide, squeeze or throw the product into fire; Stop using the product if the battery is swollen.
2. Do not place the product in a high temperature environment.
3. Do not immerse this product in water or any other liquid.
4. If short circuit fault occurs, do not continue using or disassemble without authorization. Please contact Norwii for assistance.

I. Instructions before use

1. Before using this product, please switch the input method of your computer to English input mode.
2. Please firstly run Norwii Presenter software on your computer to experience all the features of this product. Please visit Norwii official website www.norwii.com, then go to the "Software Download" page under the "Service and Support" to download Norwii Presenter software.
3. Norwii Presenter software requires three permissions in macOS: Accessibility, input monitoring, Screen & System Audio Recording in Norwii Presenter software, click "About" >"Grant Permissions", to set the three permissions.

II. Connection methods

There are two connection methods between wireless presenters and computer. One is to connect through the USB receiver, supporting USB-A and USB-C (also known as USB Type-C) interfaces, the other is to connect through Bluetooth.

USB receivers have higher priority than computer Bluetooth. After connecting the wireless presenter to the computer via Bluetooth, plug in the USB receiver, and the wireless presenter will disconnect from the computer via Bluetooth and establish a connection with the USB receiver. Pull out the USB receiver, and the wireless presenter will automatically connect to the computer via Bluetooth. The wireless presenter cannot be paired with computer via Bluetooth when the USB receiver is plugged in.

1. Connect computer through the USB receiver.

There are two types of USB receivers. One is the dual-head receiver, which contains USB-A and USB-C connectors and has no USB disk. The other is the USB disk receiver, which is USB-A connector with internal USB disk. There is only one kind of USB receiver in a package, either the dual-head receiver or the USB disk receiver,

not both types of USB receivers at the same time.

1) Turn on the power of the wireless presenter and take out the USB receiver from the rear of the wireless presenter.



2) Insert the USB receiver into the USB port of your computer, and the bottom right corner of the Windows computer desktop will display "Found New Hardware", and Windows will automatically install the driver. When Windows displays "New hardware installed and ready to use", it means that the USB receiver installation is complete, and then you can control the computer via the wireless presenter.

2. Bluetooth connection on Windows computer.

1) On computer, turn on the Bluetooth switch, click Add Device, and select Bluetooth as the device type.

2) Turn off the power of the wireless

presenter, press and hold the wireless presenter's page up key, turn on the wireless presenter's power switch, then release the wireless presenter's page up key. At this time, the wireless presenter's LED will flash, indicating that it is waiting for pairing in the following 3 minutes.

3) On the computer, find the "Norwii presenter" or "Norwii N10s Pro" in the "Add device", click connect, and at the same time, the presenter indicator light is off, and display "Norwii presenter" or "Norwii N10s Pro" connected in "Bluetooth & device". The presenter can now control the computer.

4) The Bluetooth of the wireless presenter only saves the last connected device (computer, iPad, mobile phone, etc.). When the wireless presenter turns on the next time, it will automatically connect to the last connected device. Suppose that the Bluetooth of the wireless presenter is first paired with computer A, and then paired with computer B. When turning on the wireless presenter the next time, it will automatically connect to computer B, cannot connect to computer A. At this time, if you want to reconnect to computer A, you must remove the wireless presenter in "Settings - Bluetooth & device" of

computer A, for example, remove the Norwii Presenter or Norwii N10s Pro, and then pair with computer A again to control computer A.

3. Bluetooth connection on macOS computer.

1) On computer, select Bluetooth in the computer System Settings and turn on the Bluetooth switch.


2) Turn off the power of the wireless presenter, press and hold the wireless presenter's page up key, turn on the wireless presenter's power switch, then release the wireless presenter's page up key. At this time, the wireless presenter's LED will flash, indicating that it was waiting for pairing in the following 3 minutes.

3) On the computer, find the "Norwii presenter" or "Norwii N10s Pro" on "Nearby Devices", click connect, and at the same time, the presenter indicator light is off, and display "Norwii presenter" or "Norwii N10s Pro" connected in "My Computer". The presenter can now control the computer.


4) The Bluetooth wireless presenter only saves the last connected device (computer, iPad, mobile phone, etc.). When the wireless presenter turns on the next time, it will automatically connect to the last connected device.

Suppose that the Bluetooth of the wireless presenter is first paired with computer A, and then paired with computer B. When turning on the wireless presenter the next time, it will automatically connect to computer B, cannot connect to computer A. At this time, if you want to reconnect to computer A, you must click "Forget This Device" in "Launchpad - System settings - Bluetooth - My Devices" to forget the wireless presenter of computer A, for example, forget the Norwii Presenter or Norwii N10s Pro, and then pair with computer A again to control computer A.

III. Bluetooth connectivity



IV. Function map



V. Product specifications

Transmitter

Technology:	Radio frequency
Frequency:	2.4GHz
Control Distance:	100 meters
Laser Power:	<1mW (Class 2) or <5mW (Class 3R), see the laser label on the back of the presenter.
Laser Distance:	>200m
Wavelength:	Red 640-660nm
Wavelength:	Green 495-545nm
Battery capacity:	360mAh lithium battery
Working Voltage:	3.6V-4.2V
Charging Voltage:	5V
Dimension:	150.5*26.3*15.8mm
Weight:	44g

USB-A and USB-C receiver

Working Voltage:	4.5-5.5V
Dimension:	40*14*6.4mm
Weight:	3.7g

USB-A and USB disk receiver

Working Voltage:	4.5-5.5V
Dimension:	35*14*8mm
Weight:	3.2g

VI. Operation system


Support Windows 7/8/10/11 and macOS 10.15 or later, only support laser and page up/down on Android & Linux.

VII. Package contents

1. Wireless presenter * 1 (USB receiver stored inside the wireless presenter)
2. Wireless Presenter Bag * 1
3. User Manual * 1
4. charging cable * 1

VIII. Function Description

1. Page up key : click to previous page, long press to play slides from the current page. Long press again to end slide show.
2. Page down key : click to next page, long press to enter black screen, long press again to exit black screen.
3. Physical laser key : Press and hold to turn on the physical laser beam, and release to turn off the physical laser beam.
4. Pointer key : When the Norwii Presenter software is running, double-click  to switch among function modes and use the following functions:
 - 1) Digital laser
In digital laser mode, long press  pointer key to display the default red spot. During use, press the Page up or Page down key simultaneously to expand or reduce the size of the spot. The color of the spot can be modified in the Norwii Presenter software.



2) Highlight

In highlight mode, press and hold  pointer key to display the aperture, which can highlight the content within the aperture. While holding  pointer key, press  Page up or  Page down to adjust the aperture size.



3) Magnifier

In magnifier mode, press and hold  pointer key to display the default magnifier, which can enlarge the details of the content. Press and hold  pointer key while pressing  Page up or  Page down to adjust the size

of the magnifier.



4) Air mouse

In air mouse mode, click  pointer key is equivalent to click the left key of mouse. Long press  pointer key and move hand to move mouse cursor, release  pointer key to stop moving mouse cursor. No double-click and long press the left key of mouse.



5. Pointer key : When the Norwii Presenter software is not running, Pointer key has two modes, the presentation mode and mouse mode.

The default mode is the presentation mode, which can be switched by double-clicking the Pointer key.

1) In presentation mode, click has no function to prevent forwarding slide when clicked. When long pressing, you can use the built-in digital laser function of PowerPoint in the full-screen state of PowerPoint.

2) In mouse mode, a click is a mouse left click, and you can click a hyperlink.

6. Touch screen writing: One end of the wireless presenter has a touch screen pen head, which can be used for writing and tapping on the touch screen. The touch screen pen head can be easily replaced without worrying about being damaged and unusable.



7. Mark key/Eraser key

Click the mark key , the cursor enters the mark state, hold down the mark key  and move the wireless presenter to freely draw lines on the screen. Release the mark key  to pause annotation. Click the eraser key  to erase the annotations on the screen and exit mark state.



8. volume control

Long press  the volume key up to 1 second, then move the wireless presenter up or down to adjust the computer volume.



IX. Charging instructions

1. This product can be fully charged within 2 hours of charging.
2. This product only supports standard 5V charging and does not support various quick charging. It cannot be charged with a voltage higher than 5V and may burn out the product.

LED Status	Status Description
Low battery	Blue light
Charging	Red light
Charged	Green light

X. FAQ

1. The laser is normal, and the USB receiver can be recognized by the computer, but all functions of the wireless presenter cannot be used properly?

Usually Pairing can solve this problem. Please download the Norwii Presenter software and follow the Pairing instructions in the software, or you can contact our after-sales service.

2. How to detect if a wireless presenter is out of power?

Switch on the power of the wireless presenter. If the LED is not on, it indicates that the wireless presenter is out of power; If the LED flashes slowly, it indicates that the wireless presenter is low power.

3. What if the laser doesn't light up or becomes dim?

After turned on the power, press the

laser key, the LED will light up, but the laser does not light up, it means that the laser module is damaged. If the laser spot becomes dim, it may be due to low battery power. If the laser spot remains dim after being fully charged, it means that the laser module has been damaged. Please contact Norwii after-sales service for repair or replacement.

4. What if the USB receiver is plugged into the computer's USB port and the computer does not respond or cannot recognize it?

Please check whether the USB port of the computer is working properly and try another USB interface. If necessary, please try another computer to check that the problem is with the computer or USB receiver.

XI. Certifications

CE, ROHS, FDA

FCCID: 2AXGRN95

XII. Declaration of conformity

This laser product complies with EN 50689:2021 and IEC/EN 60825-1:2014/A11:2021. Complies with 21 CFR 1040.10 and 1040.11, except for deviations pursuant to Laser Notice No.50, dated June 24, 2007.

XIII. Product Support

Shanghai Norwii Technology Co., Ltd
Address: No.277 Jinfeng Road,
Pudong New Area, Shanghai, 201201,
China

Tel: 86-21-51872080

Email: support@norwii.com